

Dishwasher Protocol

1. Close door, push in plug and push **pre-wash** button to attain dishwasher temperature of 60C.
2. Load the dishes onto racks or into cages, whichever is more suitable to keep them steady.
3. After pre-wash has finished and the water is 60C, open the door.
4. Lift the cover from the small hole nearest the door and add 1/3 tablespoon of soap powder.
5. Replace soap-hole cover and load the racks/cages into the dishwasher and close the door.
6. Push the **WASH** button and leave the dishwasher running for 10 minutes minimum.
Note: Check dishes are stable and not loose in the dishwasher.
7. To stop the wash cycle after 10 minutes push the **WASH** button again.
8. Next, rinse the dishes for 10 minutes minimum by pushing the **RINSE** button.
9. To stop the rinse cycle after 10 minutes push the **RINSE** button again.
10. Open door and remove dishes to a paper towel/benchkote-lined trolley and leave to dry.
11. Pull plug to allow water to drain away.